



# Part No. J008

## Fits: Jeep Wrangler Unlimited 2004-2006

PARTS LIST:				
Qty	Part Description	Qty	Part Description	
1	Driver Side Guard	16	3/8" x 1" Self Tapping Bolts	
1	Passenger Side Guard			

**TOLL FREE SUPPORT: 866 638 4870** 

Install Time	: 30 – 60 Minutes	
	(Professional Installation)	
Install Note	: Drilling Require, you need the	
	Ratchet and Socket Set, Drill, Drill Bit	
	Set to finish the installation	

### **REMOVE CONTENTS FROM BOX. VERIFY ALL PARTS ARE PRESENT**

### READ INSTRUCTIONS CAREFULLY BEFORE STARTING INSTALLATION

#### INSTALLATION PROCEDURE

- 1. Position the guard up to the frame. Maintain a ½" minimum gap between the bottom of the vehicle and the top of the guard. Adjust the guard from front to back until it is parallel to the side of the frame while also making sure it is parallel with the side of the vehicle. (Assistance is recommended.
- 2. When you are satisfied with the placement of the guard, mark the side of the frame through the mounting holes located on the guards brackets. After you have marked all the holes place the guard to the side. Center punch the frame at the marked locations and drill a 5/16" hole in the frame. Caution: Before drilling be sure to check the backside for hazards or obstructions.
- 3. Position the guard back against the frame and line up the holes in the brackets with the holes that you just drilled on the frame. Secure the guard to the frame using the supplied self tapping bolts. Tighten all bolts at this time. (Figure 1, 2)
- 4. Repeat these steps to install the other side. Installation is now complete.

#### SIDE ROCKER GUARD SHOWN



(Figure 1)

#### SIDE ARMOR GUARD SHOWN



(Figure 2)

#### Do periodic inspections to the installation to make sure that all hardware is secure and tight.

**To protect your investment**, wax this product after installing. Regular waxing is recommended to add a protective layer over the finish. Do not use any type of polish or wax that may contain abrasives that could damage the finish.

**For stainless steel**: Aluminum polish may be used to polish small scratches and scuffs on the finish. Mild soap may be used also to clean the Sidebar.

For gloss black finishes: Mild soap may be used to clean the Sidebar.

Keystone Automotive Operations Inc. (KAO) warrants this product to be free of defects in material and workmanship at the time of purchase by the original retail consumer. KAO disclaims any other warranties, express or implied, including the warranty of fitness for a particular purpose or an intended use. If the product is found to be defective, KAO may replace or repair the product at our option, when the product is returned prepaid, with proof of purchase. Alteration to, improper installation, or misuse of this product voids the warranty. KAO's liability is limited to repair or replacement of products found to be defective, and specifically excludes liability for any incidental or consequential loss or damage.